FIG. 1




FIG 2

NATA CODE CONTROL CODE CONTROL CODE OUTPUT-A	OUTPUT-8	(0-Indino)	3-UNDUT-E	0UTPUT-F	SELECTED AND ADDRESS OF THE PROPERTY OF THE PR
CONTROL					
PACKET SIGNAL BEFORE DECODING CONTROL CODE DECODER	DECODER-B DECODER-C	DECODER-D	DECODER-E	DECODER-F	SELECTED DATA SIGNAL

